



LONG TERM (Alpha Track) Radon Test Kit INSTRUCTIONS
91 Days - 12 Month Exposure Period

For your convenience, record device #'s here

Device 1#: _____

Device 2#: _____

Device 3#: _____

DO NOT OPEN SEALED BAG UNTIL YOU ARE READY TO TEST!

Instructions are provided to you with specific steps that must be followed. InspectUSA, National Safety Products, Accustar Labs, or any of its affiliates, cannot provide any warranty remedy to you for any claims, which arise due to the failure to follow instructions.

1. **Check the expiration date on each device.** Start your test before the expiration date or results are invalid.
2. When you are ready to start the test, cut or tear open the sealed bag that contains the black device; discard the sorbit (*little cloth looking bag*). As soon as you open the bag the device is "ON" and the test has begun. **Do NOT remove the VOID sticker** or open the black plastic housing or results will be invalid.
Save the bag, this sheet & mailing envelope for returning to lab.
3. Write each device number (or place bar code) along with your name, test address, and email address on the **INFORMATION FORM** below. **Write in the test BEGINNING date!** Also indicate the location, floor level & the name of room (IE basement, living room, bedroom etc) where the device is being exposed.
4. **PLACE THE RADON DEVICE.** Device should be placed in the lowest level of the house that is regularly used for 8-10 hours per week. If you are making a follow-up measurement, the US EPA recommends placing a device on each level that is used for living space. Do **NOT** test in garage, porch, kitchen, closet, bathroom, furnace room, laundry room, root cellar, crawl space or sump. **DO NOT** place devices where they will be exposed to high humidity &/or noticeable drafts from open doors, windows, fireplace, heat/air conditioning vents etc. Hang or place each device at least 3 feet from exterior doors or windows & at least 2 feet off the floor. The device may be placed face-up or face-down. If performing a duplicate test, place 2 devices side by side, 4" apart. Leave each device in place & undisturbed for at least 91 days and up to 1 year.
5. **END THE RADON TEST.** Place device back in the bag (or use a zip lock bag), write the test ENDING date on the INFORMATION FORM below (**necessary for analysis**). **Make sure the INFORMATION FORM is complete and LEGIBLE.**
6. Record the device number(s) for your reference and ability to retrieve results online. Online results are typically available within 14 to 21 days of the lab receiving the device(s). **Get Results at: www.TestProducts.com/results**
7. Place the device(s) & information form in the mailing package. **Write your return address & seal the mailing package closed.**
Affix proper postage! Return **IMMEDIATELY to: RADON LAB, 11 AWL STREET, MEDWAY, MA 02053**
US Priority Mail with DELIVERY CONFIRMATION is recommended.
Devices must be returned within 8 days of ending the test.
If delivery of your kit is lost or delayed, we will not be responsible for invalid results or for a free replacement kit.

Reports are emailed within 2 weeks after we receive your devices.

You may access your test results on our website www.TestProducts.com/results

National Safety Products, inc.

www.TestProducts.com



CUT HERE

INFORMATION FORM

CUT HERE



Send Report To: ↓		Test address: ↓	
Name:		Name:	
Address:		Address:	
City, State, Zip:		City, State, Zip:	
eMail address:		Tech Certification (if required):	
<input type="checkbox"/> Check here if devices were placed 4" apart		<input type="checkbox"/> Check here if this test is a Post Mitigation test	
Notes:			
Device #:	Device #:	Device #:	
Floor level:	Floor level:	Floor level:	
Name of room:	Name of room:	Name of room:	
Date Opened:	Date Opened:	Date Opened:	
Date Closed:	Date Closed:	Date Closed:	

Remember to affix proper postage or Post Office will not deliver to the Lab.